

Content of this lecture

1. Excitation of SPPs

- Prism coupling
- Excitation by highly focused beam
- Grating coupling
- Excitation by scattering
- Near-field excitation
- Other coupling schemes

2. Characterization of SPPs

- Near-field microscopy
- Leakage radiation microscopy
- Fluorescence imaging
- Scattered light imaging

1. Excitation of SPPs

- To excite SPPs, the wave vector of incident light should satisfy:


$$k_x^{\text{inc}} = \beta_{\text{SPP}} \quad (\text{also called “phase-matching condition”})$$

Why? – conservation of the transverse momentum of photons!


Momentum of photons:

$$\mathbf{P} = \hbar \mathbf{k}$$

(\hbar : reduced Planck constant)




- Can SPPs be excited just by shining light on a flat metal surface?



x-component of the incident wavevector:



$$k_x^{\text{inc}} = k^{\text{inc}} \sin \theta = \sqrt{\epsilon_d} \frac{\omega}{c} \sin \theta$$




- No intersection \rightarrow phase matching condition cannot be satisfied \rightarrow **no in-coupling of light & no out-coupling of SPPs** (\therefore confined field)
- Therefore, k_x^{inc} must be **increased** by **some “tricks”** to **match** β_{SPP}

(1) Prism coupling

- In the prism, create evanescent wave by **total internal reflection (TIR)**
- Evanescent wave tunnels through the thin film to the air-metal surface
- Strong coupling when $k_{\text{SPP}} = k_{x,2}$
momentum matching




- At SPP excitation, energy is transferred from incident light to SPPs
→ a **minimum** in the reflected intensity is observed




- Dependence on film thickness**: there is an optimum thickness for perfect coupling
- Resonance **width** related to the damping (loss) of SPPs
- Excited SPPs are **leaky waves**: leakage of radiation into the prism
- Minimum caused by **destructive interference** of leakage & direct TIR

Two coupling configurations:



Kretschmann configuration

- Evaporation of metal film on the prism is needed





Otto configuration

- Avoid direct contact with the metal surface (e.g., for studies of the surface quality)
- The air gap should be well controlled to be small enough

Application example: biosensing

For monitoring biomolecules: proteins, ligands, DNA, etc.




Sensorgram

Advantages:
– real-time sensing
– no labeling




Principle:

- SPR is surface sensitive
- Antibodies are attached to gold surface
- Complementary antigen (analyte) binds to the antibodies → refractive index n_d change → **SPR-dip shift (monitored signal)**


Commercial SPR instruments:



SPRi system of K-MAC (Daejeon, Korea)





The Proteomic Processor of Lumera
(Bothell, WA, USA)



SPRi-Plex and SPRi-Lab+ system
of GenOptics (Orsay, France)

(2) Excitation by highly focused optical beams




Bouhelier and Wiederrecht, OL **30**, 884 (2005)

- Is a variation of the prism coupling – an **oil-immersion objective of high numeric aperture** is used instead of the prism
- **Off-axis** entrance of the beam \rightarrow excitation at an expected angle $> \theta_c$
- Highly focused beam \rightarrow allows for **localized SPP excitation**
- **Leakage radiation** \rightarrow observation of the SPP excitation

Application example: measurement of ultra-thin film thickness

- Measurement of Langmuir-Blodgett-Kuhn (LBK) film thickness



H. Kano and W. Knoll, Opt. Commun. 153, 235 (1998)

- Principle:** Variation of film thickness \rightarrow change effective $\varepsilon_d \rightarrow$ shift of SPR
- Coupling angle strongly depends on the film thickness of the LBK film
- Measured results: LBK thicknesses of 3.5nm, 7.3nm, 11.15nm
- Detection of just a few LBK layers is feasible!

(3) Grating coupling

- Grating can generate multiple diffraction orders (**propagating & evanescent**).
- m^{th} -order wavevector satisfies:

$$k_{m,x} = k_{\text{inc},x} + mK$$

(= grating equation, check it by yourself)



$$K = \frac{2\pi}{d}$$

- Since $k_{\text{SPP}} > k_{\text{inc}}$, only the **evanescent orders** may phase-match with SPPs:



$$k_{\text{SPP}} = k_{m,x} = k_{\text{inc},x} + mK$$



In this way, the SPPs are excited!



Understand the grating coupling in the dispersion diagram:





$$k_{SPP} = k_{m,x} = k_{inc,x} + mK$$

It seems that only positive orders can excite SPPs?

– No! Both positive & negative orders can excite!

More about the dispersion diagram:




Periodic condition

$$k_{m,x} = k_{\text{inc},x} + mK$$


The cross points between the red and blue curves indicate the coupling!

The reverse process can also take place: SPPs propagating along a grating surface can couple to light and thus radiate.

Experiment: SPPs excited by the right small grating and decoupled by the left big grating ($\square = 760$ nm)




Devaux et al., APL $\square\square$, 4936 (2003)



Near-field optical image ($\lambda = 800$ nm)


Excitation and beaming of SPPs by different orders of a 2D grating:



Egorov et al., PRB **70**, 033404 (2004).

SPP photonic bandgap structures:

- When grating is **deep** □ no longer small perturbation of the surface
- Significant changes to the SPP dispersion
- When $d \sim \lambda_{\text{SPP}}/2$: scattering leads to formation of **SPP standing waves**
→ opening of an **SPP stop band** at the **Brillouin zone edge**




Barnes et al., Nature **424**, 824 (2003).

In analogy to photonic crystals, named “surface polaritonic crystals”


Zayats and Smolyaninov, J. Opt. A: Pure Appl. Opt. **5**, S16 (2003).

Full photonic bandgap for SPPs

- Hexagonal array of metallic dots



Scanning Electron Microscopy image (tilted)




S.C. Kitson, Phys Rev Lett. 77, 2670 (1996)

- Array causes coupling between waves for which:

$$k_{sp} = \pi/P \text{ or } \lambda_{sp} = 2\pi/k_{sp} = 2P$$




- Gap opens up at the zone boundary




(4) Excitation by scattering


Atomic Force Microscopy Image



Near-field Optical Microscopy Image




Smolyaninov, PRL **77**, 3877 (1996)




- **Random structures** such as single holes, sharp edges, particles, and defects can **locally** excite SPPs.
- It happens when the defect dimension $a \ll \lambda_0$, **why?**
- Scattering generates **a broad spectrum of K vectors** (stemming from the spatial Fourier transform of the defect) in which a solution to the coupling condition $k_{\text{SPP}} = k_{\text{inc},x} + K$ can be found. (**Homework**)
- It also implies that **surface defect is a loss channel for SPP propagation!**

Ditlbacher et al., APL **80**, 404 (2002).




Phase-matching: $k_{\text{SPP}} = k_{\text{inc},x} + K$

Radiation of dipole \perp oscillation direction




Dipolar radiation pattern



- Dipole radiation in the direction of charge oscillation?! Why?


Plasmon wave is mainly longitudinal!

Scattering by sharp edge



- Radiation pattern is more directional
- If illumination over whole line \rightarrow radiation \perp line


Scattering by two dots



- Pattern results from the interference of SPPs excited by the two dipoles

(5) Near-field excitation


Hecht et al., PRL **77**, 1889 (1996).




$$a \ll \lambda_0$$

$$K > \beta > k_0$$


Phase-matching: $k_{\text{SPP}} = k_{\text{inc},x} + K$



probe aperture



two optical setups




silver film

- Suitable for **local** SPP excitation
- May act as a nanoscale **SPP point source**
- Useful for characterizing the effect of surface roughness on SPPs and the scattering at individual surface defects with high spatial resolution


(6) Some other coupling schemes

These are more or less some variations of previous coupling techniques:





Waveguide coupling

Homola, Chem. Rev. **108**, 462 (2008).





Coupling with optical fiber taper


Maier et al., APL **84**, 3990 (2004).





End-fire coupling



Kim et al., Opt. Express **18**, 10609 (2010).



Experiment



3. Characterization of SPPs


How to see or detect SPPs?

- **Near-field microscopy**
 - **Leakage radiation microscopy**
 - **Fluorescence imaging**
 - **Scattered light imaging**
- ← Commonly used methods

(1) Near-field microscopy


- SPP waves are generated by prism coupling
- Imaging the SPP waves by Scanning Near-field Optical Microscope (SNOM)
- Insert the probe tip to “near field” to convert it to propagating wave
- Near-field optics is essential!

More about near-field optics and SNOM system will be studied in [lecture 11](#)




SNOM optical image:
 $S = S(x_{\text{probe}}, y_{\text{probe}})$

detector




Example: SPP scattering by an individual defect;
45-nm-thick silver film on a glass prism;
 $\lambda = 633 \text{ nm}$, p-polarization; image size $3 \times 3 \mu\text{m}^2$



Notice parabolic shape of interference fringes (!)



One should control that the SNOM signal is dominated by the SP contribution (i.e., out-of-plane scattering is weak)!

Experimental setup for the **local** SP excitation and SNOM imaging at different wavelengths




Gold films: direct determination of the SP propagation length at different wavelengths


$\lambda = 633 \text{ nm}$



$\lambda = 790 \text{ nm}$







$\lambda = 1520 \text{ nm}$




Opt. Express **13**, 3303 (2005)

(2) Leakage radiation microscopy




Further reading: Drezet et al., Materials Science and Engineering B **149**, 220 (2008).



Directly transmitted light is not filtered

- Direct imaging of SPP modes in a 2D grating



Tetz et al., APL **86**, 111110 (2005).








Image in the Fourier plane:




Images in the image plane:



(3) Fluorescence imaging




Ditlbacher et al., APL 80, 404 (2002).




- Rely on the **fluorescence of organic molecules** placed in the vicinity of the SPP-carrying metal surface
- Fluorescence images have to be **recorded within a limited time** (typically a few seconds) because of **molecule bleaching**
- Fluorescence intensity is in general **not proportional** to the local SPP field intensity → not suitable for quantitative measurement

(4) Scattered light imaging



- Can be used to map out the **dispersion relation** and **band gaps of SPPs** on modulated surfaces.

- SPP propagation is imaged by collecting the **light lost to radiation due to scattering** at metal surface.
- **Surface roughness is important!** For high-quality flat surface, scattering is weak.



Depine and Ledesma, Opt. Lett. **29**, 2216 (2004).

Summary

► Excitation of SPPs:

SPPs cannot be excited directly by light on a planar surface;
Understand the principles and characteristics of different coupling methods:

- Prism coupling
- Grating coupling
- Near-field excitation
- Excitation by highly focused beam
- Excitation by scattering
- Some other coupling schemes

► Characterization of SPPs:

Four commonly used imaging methods:

- Near-field microscopy
- Fluorescence imaging
- Leakage radiation microscopy
- Scattered light imaging

Understand their principles and advantages/disadvantages.